


Customer Installation Instructions

Power- Space Saver, Rocker, Swivel Glider, and 1 Motor Lift

14022




Included in Package: **A.** Instruction Sheet **B.** Cord Extender
C. Wall Transformer


Powered Head Tilt Option



2. Attach corresponding headtilt wires from "Back" to "Base".
Note: This step is for powered head tilt only.



1. Attach "Back" to "Base" unit by aligning the back clips with mechanism bracket. Slide together until they snap into place.



3. Pull bottom "Back" flap down and connect sewn velcro with velcro on the inside edge of base frame and snap both lower brass buttons.



Note: Ensure clasps on B and C are closed.

4. Connect wire from bottom of "Base" unit to cord extender.
5. Connect end of Wall transformer cord to cord extender.
6. Plug wall transformer into wall outlet. Your new recliner is ready to use. If a problem occurs, contact dealer.

For BeCozzi Recliner instructions see reverse side.

Warning: Keep transformer clear of debris and in a ventilated space. Keep all wires clear of the recliner mechanism components.