


pottery barn kids

MY FIRST PLAY TABLE

IMPORTANT SAFETY INSTRUCTIONS:

Please read all instructions carefully before assembling.
For your safety, assembly by two adults is recommended.



PART LIST

- (A) Table Top – 1pc
- (B) Leg – 4pcs

HARDWARE LIST


- (C) Wrench  - 1pc
- (D) Nut 5/16"  - 8pcs
- (E) Spring Washer 5/16"  - 8pcs
- (F) Flat Washer 5/16"  - 8pcs

PRE-ASSEMBLY:

- Remove all parts and hardware from the box and lay out on a clean, carpeted, or scratch-free work surface, as this will avoid damaging any parts during assembly. The shipping box provides an ideal work surface. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists above to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- Note: Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- If using power tools to aid in assembly please use caution. Power tools can damage hardware or split wood.

ASSEMBLY INSTRUCTIONS:

1. Carefully place the Table Top (A) face-down on a scratch-free work surface.
2. Insert the threaded bolts on one of the Legs (B) into the pre-drilled holes located on the corner of the underside of the Tabletop (A) and secure in place with a Flat Washer (F), Spring Washer (E), and then, a Nut (D) onto the Leg's (B) bolt, as shown below. Loosely tighten with the Wrench (C). Repeat with the remaining Legs (B).
3. Turn the assembled table upright. Check alignments and then, fully tighten all nuts.



CARE INSTRUCTIONS:

- Dust with a clean, soft cloth.
- Bolt spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.
- Do not stand on the table top at any time.