


pottery barn kids

ANDERSON NIGHTSTAND

IMPORTANT SAFETY INSTRUCTIONS:

Please read all instructions carefully before assembling.
For your safety, assembly by two adults is recommended.



PARTS INCLUDED:


- (A) Nightstand – 1pc
- (B) Bun Foot— 4pcs

PRE-ASSEMBLY:

- Remove all parts and hardware from the box and lay out on a clean, carpeted, or scratch-free work surface, as this will avoid damaging any parts during assembly. The shipping box provides an ideal work surface. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists above to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- Note: Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- If using power tools to aid in assembly please use caution. Power tools can damage hardware or split wood.

ASSEMBLY INSTRUCTIONS:

1. Place the Nightstand (A) on its back on a clean, carpeted work surface.
2. Thread the (4) Bun Feet (B) into the inserted nuts located on bottom of the piece by turning it clockwise.
3. Turn the Nightstand (A) upright. Adjust the adjustable levelers on the bottom of the Bun Feet (B) by loosening or tightening them so the Nightstand (A) sits evenly on floor, if required.



CARE INSTRUCTIONS:

- Dust with a clean, soft cloth.
- Bolt spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.

Thank you for your purchase.
stores | catalog | www.potterybarnkids.com
USA 1.800.290.8181