


pottery barn kids

CHALKBOARD ARMOIRE

PRE-ASSEMBLY:

- For your safety and ease, assembly by two adults is recommended.
- Please read all instructions before beginning assembly. The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- Remove all parts and hardware from box and lay out on a carpeted or scratch-free work surface. The shipping box provides an ideal work surface. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists to identify and separate each of the pieces included prior to starting assembly.
- Note: DO not fully tighten the bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- The use of power tools for assembly is not recommended. Power tools can damage hardware or split wood.




PARTS INCLUDED:

- (A) Armoire – 1pc
- (B) Shelf – 1pc
- (C) Hanging Rod – 1pc


TOOLS REQUIRED:

Philips Screwdriver (Not included)



ASSEMBLY INSTRUCTIONS:

1. Place the Hanging Rod (C) on the hanging brackets inside the armoire.
2. To change the shelf position, unscrew the Shelf Supporters located beneath the Shelf (B) with a Philips Screwdriver. Move Shelf Supporters to the desired position and place the Shelf (B) on the Shelf Supporters. Use the screws to re-secure the shelf if desired.



CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.

Thank you for your purchase.
stores | catalog | www.potterybarnkids.com
USA 1.800.290.8181